

Specification Sheet No

MP 02 Description

THEATRE PUR MAINTENANCE INDUSTROCLEAN

Date

JULY 2024

MAINTENANCE PROCEDURE

General Guidelines:

PUR vinyl sheeting and tiles feature a cross-linked high quality polyurethane reinforcement. The floor should not be stripped or sealed. Never use a Black Pad on a PUR floor.

For ease of maintenance in operating theatres, it is recommended to apply 2-3 layers sacrificial layers of Proflor HD sealer.

NOTES: We highly recommend an effective barrier/entrance matting system to reduce the dirt tracked into the building.

Post Installation & Periodic Cleaning

Step 1:

- All dust, sand and stones must be removed prior to scrubbing. This can be done with either a vacuum cleaner or by sweeping with a disposable cloth system such as Masslinn® Tool and Masslinn® Cloths.
- Scrub the floor using a solution of a neutral detergent such as Proclean diluted according to manufacturer's instructions, with a Low-Speed Scrubber fitted with a 3M Blue Cleaner Pad. For detail work, use an edge cleaning tool with blue pad.

Step 2:

- Vacuum the dirty Proclean solution from the floor with a Wet & Dry Vacuum Cleaner. The floor should be thoroughly rinsed with clean water to remove any remaining chemical residue.
- If no machine is available, remove the solution from the floor using a mop and mopping system.

 The water and mop must be changed frequently so as to remove as much chemical residue as possible from the floor.

Daily Maintenance:

- 1. Dust sweep with a disposable cloth system such as Masslinn® Tool and Masslinn® Cloths.
- Spot mop wet sticky dirt with a double/single bucket mopping unit with the correct dilution of neutral detergent such as Proclean. For optimal results, make sure that the rinsing water is changed regularly.
- 3. For larger areas, wash the floor using a Nilfisk Automatic Scrubber-Drier, 3M Red Buffing Pad and low foam neutral detergent such as Proslip.
- 4. For a sheen, buff using a high-speed machine with Probuff spray buff & Red 3M Floor Pad. Alternatively, a Green Eco Brilliance Diamond Pad can also be used in conjunction with an autoscrubber or buffing machine.

Periodic Cleaning:

The floor may require periodic scrubbing in high traffic areas. In such cases, follow the aforementioned Post Installation and Periodic Cleaning guidelines.

Cleaning of Equipment:

- 1. All equipment should be cleaned thoroughly after use.
- 2. Pads should be rinsed or vacuumed depending on soiling.
- 3. Single disc machines must be wiped with a damp cloth and disinfectant if needed.

Industroclean (011) 801 4600.

SPECIALIST FLOORING & WALL PROTECTION PARTNER

