

Specification Sheet No

PSA 157 Description

MC17c SET-IN SKIRTING

Date

MAY 2023

ARCHITECTURAL SPECIFICATION / BOQ

SPECIFICATION:

Supply fully flexible MC17c Set-In Skirting (100 x 70mm) to ensure a tight radius to prevent dirt collecting in corners and to be of such a radius to prevent cleaning machines striking the curve of the sheeting up the wall. Install MC17c Set-In Skirting as per installation procedure below.

Colour: Code:

INSTALLATION: (PLEASE NOTE: ALWAYS USE COMPATIBLE PRODUCTS FROM ONE SUPPLIER)

Install MC17c Set-In Skirting:

- 100mm up the wall
- 50mm on the floor
- 20mm allowance for wall deviation and to overlap & scribe.

Ensure PC20 Cove Former is installed prior to the MC17c Set-In Skirting.

Skirting of this type must preferably be fitted after the flooring is laid, must be overlapped with sheeting/skirting, and scribed to a tight joint, then grooved with a hand groover or electrical groover. Welded to the flooring, this provides a secure joint.

Ensure that all surfaces are firm, dry, and free of dust, grease, and oil. All painted surfaces must be stripped back, and wire brushed to remove all traces of paint.

Always observe the adhesive manufacturer's instructions. Pay attention to use of solvent-based adhesives, especially regarding ventilation and possible sources of ignition.

Apply Polyflor recommended contact adhesive to both surfaces, allow adhesive to flash off and then adhere coving to area where the floor meets the wall. Apply pressure to create a firm bond.

All fitting work must be carried out accurately prior to application of adhesive, as movement afterwards is restricted. Adjustments for length should always be made on straight joints –never on mitred sections – unless the length of the wall does not permit this.

MAINTENANCE:

The MC17C coving must be washed with a neutral detergent and buffed to remove any scuff marks.

This program will keep maintenance costs to a minimum.