

SPECIFICATION
SHEET NO:

PSA
178

DESCRIPTION:

MC8c SIT-ON COVING

DATE:

MAY
2023

ARCHITECTURAL SPECIFICATIONS / BOQ

SPECIFICATION:

Supply and install fully flexible MC8 Sit-On Coving (20 x 100mm) to ensure a tight radius to prevent dirt collecting in corners.

Colour:

Code:

INSTALLATION: (PLEASE NOTE: ALWAYS USE COMPATIBLE PRODUCTS FROM ONE SUPPLIER)

Sit-on skirting is only to be used in conjunction with tiled floors to provide a finish around the perimeter of the room. The sit-on skirting is adhered to the walls and the toe of the skirting sits on top of the floor; it is not welded. If requested suitable mastic sealant can be used beneath the toe of the skirting.

Ensure that all surfaces are firm, dry, and free of dust, grease, and oil. All painted surfaces must be stripped back, and wire brushed to remove all traces of paint.

Always observe the adhesive manufacturer's instructions. Pay attention to use of solvent-based adhesives, especially regarding ventilation and possible sources of ignition.

Apply Polyflor recommended contact adhesive to both surfaces, allow adhesive to flash off and then adhere coving to area where the floor meets the wall. Apply pressure to create a firm bond.

All fitting work must be carried out accurately prior to application of adhesive, as movement afterwards is restricted. Adjustments for length should always be made on straight joints –never on mitred sections – unless the length of the wall does not permit this.

MAINTENANCE:

The MC8c coving must be washed with a neutral detergent and buffed to remove any scuff marks.

This program will keep maintenance costs to a minimum.

SPECIALIST FLOORING & WALL PROTECTION PARTNER

Tel: 011 609 3500 | Email: marketing@polyflor.co.za | www.polyflor.co.za
Poly Sales House, 8B Buwbes Road North, Sebenza, 1609, South Africa. PO Box 3967, Edenvale, 1610, South Africa

Poly Sales Africa (Pty) Ltd. trading as Polyflor South Africa. Company Registration 2004/012256/07