

SPECIFICATION SHEET
NO:

PSA
78

DESCRIPTION:

Gradus AVR5020
Aluminium Floor Trim

DATE:

APR
2024

ARCHITECTURAL SPECIFICATION / BOQ

SPECIFICATION:

Supply and install AVR5020 an aluminium floor trim designed to repair resilient floorcoverings where welded joints have failed, utilizing strips of the same floorcovering as an insert to provide an unobtrusive repair. Ideal for use in environments that endure heavy wheeled and pedestrian traffic. AVR5020 can also be installed at door interfaces to provide robust transition. Pre-installation floor preparation as per manufacturers' data sheet.

INSTALLATION: (PLEASE NOTE: ALWAYS USE COMPATIBLE PRODUCTS FROM ONE SUPPLIER)

1. It should be ensured that all surfaces to which the profile is to be fixed are dry, flat, and free from any contaminants.
2. Cut the profile to the size required. Using the template provided, mark and cut the material being used for the coordinating insert to the length/width required.
3. Place the profile in position and mark the position of the screw holes onto the substrate.
4. Drill the substrate to a depth of 25 -30mm and insert suitable fixing plugs into the holes.
5. Apply neoprene-based cartridge adhesive to the back of the profile and place onto the substrate. Ensure that all of the profile is in contact with the substrate.
6. Using No.6 screws fix through the profile, into the plugs and tighten.
7. Apply contact adhesive to the channel of the AVR 50, ensuring that complete coverage is achieved, apply the same adhesive to the back of the material being used for the insert. Allow the adhesive to dry and bring the two surfaces together, roll and clean off any excess adhesive.

SPECIALIST FLOORING & WALL PROTECTION PARTNER

Tel: 011 609 3500 | Email: marketing@polyflor.co.za | www.polyflor.co.za
Poly Sales House, 8B Buwbes Road North, Sebenza, 1609, South Africa. PO Box 3967, Edenvale, 1610, South Africa

MAINTENANCE:

Preventative Maintenance Programme

A regular scheduled maintenance programme prevents buildup of dirt and grease, which will reduce the anti-slip properties of the profile and detract from the overall appearance of the product.

Daily Cleaning

Brush down the profiles using a soft bristled brush and remove dust particles by wiping with a damp cloth.

Twice Weekly

Brush down the profiles using a soft bristled brush. With clean warm water, apply a small amount of soap-less detergent to a wet green scotch pad and gently clean the surface of the profile along its width. During the clean, the water must be changed on a regular basis. Do not soak the profile. Once the profile has been cleaned thoroughly rinse with fresh, clean water and dry with a dry lint free cloth.

On completion the profile should not be used until completely dry.

Aluminium Profiles

Stubborn marks such as boot blacking may be removed from the aluminium profile by means of a green scotch pad and soap-less detergent. Light surface scratches can be removed with careful use of fine wire wool and buffed with a soft cloth.

The maintenance regime requires the installation of an effective barrier matting system