

SPECIFICATION SHEET  
NO:

PSA  
97

DESCRIPTION:

GRADUS WGA100 WALL  
GUARD

DATE:

SEPT  
2023


### ARCHITECTURAL SPECIFICATION / BOQ

#### SPECIFICATION:

Supply and install WGA100 wall guard comprising a continuous aluminium retainer, PVC-u cover and PVC-u end caps, been designed to provide a tight fit to the wall to minimize the collection of dirt and dust, with covers that are replaceable if damaged by heavy impact and are through-coloured and textured to conceal the effects of impact and abrasion, with end caps including black reveals that provide a tight, neat joint and contain an anti-microbial agent to inhibit the growth of bacteria, having an angled design making it ideal for providing indirect protection and keeping traffic of different heights away from the wall, available in 33 colour options, supplied in 4.00m lengths

Colour:

Code:



### SPECIALIST FLOORING & WALL PROTECTION PARTNER

Tel: 011 609 3500 | Email: [marketing@polyflor.co.za](mailto:marketing@polyflor.co.za) | [www.polyflor.co.za](http://www.polyflor.co.za)  
Poly Sales House, 8B Buwbes Road North, Sebenza, 1609, South Africa. PO Box 3967, Edenvale, 1610, South Africa


Poly Sales Africa (Pty) Ltd. trading as Polyflor South Africa. Company Registration 2004/012256/07

### Installation:

1. Cut the aluminium retainer to the desired length, allowing 50mm clearance for each end cap and an additional 25mm clearance so that the end caps can be fitted and removed when placed near an architrave or wall. For internal corners, where closely positioned endcaps would reduce the clearance between them too much, it is necessary to reduce the retainer length a further 25mm.
2. Using a 6.0mm drill bit, drill holes in the aluminium retainer using the v-notch in the centre at 50mm from each end and spaced evenly between the end holes at a pitch of 9 anchor points per 4.00m length (i.e., approximately 500mm apart). Using the same 6mm drill bit, drill an additional hole 10mm from each end also along the v-notch to accommodate the bolt for endcaps where required.
3. Using an alignment laser, position the retainer against the wall at the desired height, aligning the v-notch on the centreline of the retainer with the laser level. When positioning horizontally, allow for the end caps which need to be 25mm away from any hindering wall (50mm for internal corner). With the retainer in the desired position, mark the locations of the mounting holes on the wall with a marker. Drill all marked holes to the correct depth on the wall with a drill bit suitable for the screws and wall plug fixings being used (not supplied).
4. Before fitting the end caps, measure the length of the retainer and add 7mm which will be used as the cut length for the PVC-u cover. Joints in the PVC-u cover should ideally not coincide with joints in the retainer. Joints of the retainer and the PVC-u cover should be staggered and should be at least 300mm apart.
5. To secure the endcaps, put the washer on the bolt, push the bolt through the back of the retainer and fit the flanged nut.
6. Loosely attach the retainer to the wall using one screw at either end. Check alignment of all remaining holes in the retainer with the holes in the wall while maintaining alignment of centreline of the retainer with the laser level. Correct any misaligned hole positions before fitting the endcaps.
7. Cut the PVC-u cover as per point 4, taking care to ensure that the cuts are both square and clean. Loosely position the cover on the aluminium retainer to check the fit length, adjusting if necessary. Hook the top edge of the cover over the top edge of the retainer while butting the cover up against one of the reveals. Press the base of the cover downwards towards the base of the aluminium retainer until it snaps into place. Approximately 300mm from the second reveal, fold the end of the profile inwards towards the reveal/endcap so that there is a compressive force on the PVC-u cover against both endcaps/reveals to keep everything flush when the final section is snapped into place. If the length required is over 4 metres, clip one cover on entirely and then butt join subsequent cover pieces ensuring the ends are cut square to allow for a tight join. To finish the run, follow the procedure above for fitting the final piece. The length of the PVC-u cover sections in any one run should be planned so that the final piece is not too short or close to the end cap both for aesthetics and ease of fitting. Wherever possible try and even out the lengths of the cover (i.e., for a 4.5 metre length consider using a 2m and a 2.5m length instead of a 4m & 0.5m length) whilst ensuring that joints are minimised and staggered (as per point 4).

### Fitters Tips:

- ☐ The PVC-u cover may try and compress under the pressure of the saw blade during the cutting process. This can be reduced by cutting very slowly.



#### **MAINTENANCE:**

A regular scheduled maintenance programme should be employed to prevent the build-up of dirt and grease, which will detract from the overall appearance of the product and can lead to the spread of germs and bacteria.

Apply a neutral cleaner to a micro fibre cloth and wipe the surface of the profile. When cleaning handrails, particular attention should be paid to the underside of the handrail as this is where dirt and grease can build up.

The cleaned surface should then be 'rinse wiped' using clean water and then thoroughly dried using a soft cloth. This ensures all cleaning residue is removed.

**Abrasive cleaners, solvents, or cleaning pads (e.g., Thinners, Turpentine, Handy Andy) should NOT be used as they will damage the profile surface.**